

## Product Features

- Designed for use with media with which a regular cast iron or steel barrel pump cannot be used
- Pump body is made from glass filled polypropylene with Ryton veins
- All seals are from Viton & all pump hardware is Stainless Steel
- Strainer fitted at the suction tube inlet stops contaminants from entering the pump
- Complete with threaded polypropylene suction tube & a choice of two 2" bung adaptors for use on both plastic & metal drums of capacity 15 gallons (50 litre) – 55 gallons (205 litre)

### WETTED COMPONENTS

Polypropylene, Ryton, Viton & Stainless Steel

### RECOMMENDED USE

For dispensing water based media, antifreeze, **Urea, Adblue, DEF**, Benzene, Detergents, Glycerine, acids, chemicals etc., in addition to use with all light weight petroleum based products

### DO NOT USE

With Acetone, Lacquer, Mineral Oils, Solvents, Turpentine etc.

### DELIVERS



5 litres (1.3 gallon)  
per 20 turns

## Ordering Information

CAT. NR.	ORDERING NR.
PRP/01	44191



Stainless steel hardware

Bung with 2" threads

Strainer

